


instruction manual

evo projector - supplemental



10. Replacing the projector's lenses.

CAUTION lens housing may be extremely hot. Allow to cool before touching.

- i. Detach lens housing, as shown in Section 6 - "Installing a gobo pattern".
- ii. Remove lens retaining screws and extract the lenses carefully.
- iii. Separate the two lens holders. To remove lenses, first remove retaining clip and then lens.
- iv. Replace lens and secure in place using the retaining clip.
- v. Combine the lens holders and insert back into lens housing. Be sure to align the threaded bars.
- vi. Secure in place using the four lens retaining screws.
- vii. Reconnect the lens housing to the main projector body.

